

How to Adapt FLEX-Drain® to an ADS Tee

Holding the ADS tee, insert a FLEX-Drain® Coupler into the tee just inside the outer cuff. This should give you a snug fit.



Collapse 2 or 3 corrugations of the male end (small or cut end) of FLEX-Drain® and insert into the coupler.



Pull gently to create a barb fitting in the corrugations of the coupler.



www.flex-drain.com
1-800-257-1722

© 2006 Cleveland Tubing, Inc.