

## How to adapt FLEX-Drain® to 4" PVC

Collapse 2 or 3 corrugations in the male end (smaller or cut end) of FLEX-Drain® and insert into PVC pipe.



This will be a fairly snug fit.



[www.flex-drain.com](http://www.flex-drain.com)  
1-800-257-1722

© 2006 Cleveland Tubing, Inc.