

## How to adapt FLEX-Drain® to 4" corrugated black plastic pipe

Collapse 2 or 3 corrugations of the male (smaller or cut end) of FLEX-Drain® and insert into the corrugations of the corrugated pipe.



Pull gently to create a barb fitting in the corrugations of the pipe.



[www.flex-drain.com](http://www.flex-drain.com)  
1-800-257-1722

© 2006 Cleveland Tubing, Inc.