

How to adapt FLEX-Drain® to an ADS Wye:

Holding the ADS wye, insert a FLEX-Drain® Coupler in the wye just inside the outer cuff—it will be a snug fit.



Collapse the first 2 or 3 corrugations of the male end (smaller or cut end) of FLEX-Drain® and insert it into the coupler.



Pull gently to create a “barb fitting” in the corrugations of the coupler.



www.flex-drain.com
1-800-257-1722

© 2006 Cleveland Tubing, Inc.