

How to adapt FLEX-Drain® to a Hancor Tee

Place tee on the ground and collapse first 2 or 3 corrugations of FLEX-Drain® and insert FLEX-Drain® into the corrugations of the tee.



When FLEX-Drain® is engaged with the corrugations, pull gently to create a barb fitting in the corrugations of the tee.



www.flex-drain.com
1-800-257-1722

© 2006 Cleveland Tubing, Inc.