

## Splicing cut FLEX-Drain® with a FLEX-Drain® Coupler

Collapse the first 2 or 3 corrugations of both pieces of FLEX-Drain®.  
Insert FLEX-Drain® into the corrugations of the FLEX-Drain® Coupler.



When FLEX-Drain® is engaged with the corrugations pull gently to create a barb fitting in the corrugations of FLEX-Drain® Coupler.



Repeat the operation with other piece of FLEX-Drain®



[www.flex-drain.com](http://www.flex-drain.com)  
1-800-257-1722

© 2006 Cleveland Tubing, Inc.